



Probing Nanostructures and Optoelectronic Properties of Organic Solar Cells by Conductive and Photoconductive AFM

Thuc-Quyen Nguyen

Chemistry and Biochemistry Department, University of California, Santa Barbara (UCSB), USA

Organic solar cells have obtained much attention in both academia and industry because they have the potential to produce low-cost plastic devices for alternative energy sources. In these devices, the performance depends strongly on the nanoscale film morphology and optoelectronic properties; therefore, it is important to control the nanoscale morphology and to probe these properties and correlate to the bulk measurements. We combine conducting and photoconductive atomic force microscopy (c-AFM and pc-AFM) to study nanoscale morphology and device physics of bulk heterojunction solar cells based on small molecules and low band gap conjugated polymers blended with [6,6] phenyl-C71-butyric acid methyl ester. In c-AFM, the conducting probe makes contact with the sample (the tip acts as a nanoelectrode) and measures dark- or photo-current as a function of applied voltage either at certain points on a surface or maps out a current image at a fixed bias. We demonstrated that substantial insight at the nanoscale can be obtained by using the c-AFM: 1) Nanoscale charge carrier transport, 2) Photocharge generation, 3) Assigning donor and acceptor phase separation domains, 4) Mapping donor-acceptor networks, both laterally and vertically, 5) Surface charge distributions, 6) Film quality by examining charge mobility distribution, and 7) Device physics. C-AFM is also employed to study inorganic and perovskite solar cells. The results demonstrate that c-AFM and pc-AFM are powerful techniques to characterize solar cell materials and can be used to understand the bulk performance.